# SHORELINE® & SHORELINE® MINI



**INSTALLATION GUIDE** 





# LYSAGHT SHORELINE® GUTTER & SHORELINE® MINI GUTTER

# Stylish and contemporary gutter profiles

LYSAGHT SHORELINE<sup>®</sup> Gutter & SHORELINE<sup>®</sup> MINI Gutter profiles are the perfect choice for contemporary homes requiring a modern appearance. It has a high rainfall carrying capacity and can be installed onto NOVALINE<sup>®</sup> Fascia or Timber Fascia.

# INSTALLATION

# LYSAGHT SHORELINE® GUTTER

# INSTALLATION TO NOVALINE® FASCIA

- 1. Using a NOVALINE® Fascia spring clip, secure the back of the SHORELINE® or SHORELINE® MINI Gutter to the fascia.
- 2. Use a SHORELINE® Gutter overstrap to secure the front scroll of the gutter, then fasten to the top edge of the NOVALINE® Fascia and back on to the rafter.

# **INSTALLATION TO TIMBER FASCIA**

- 1. Fasten a Timber Fascia Suspension Clip to the timber fascia using #8-10x32 CSK Ribbed Head, Coarse Thread Timber screw with Climacoat 3 for treated timber. Subsequent clips can be fixed at any level on the fascia to accommodate the fall/slope of the gutter.
- 2. Secure the SHORELINE® Gutter to the desired barb on the timber fascia suspension clip.
- 3. Use a SHORELINE® Gutter overstrap to secure the front scroll of the gutter, then fasten to the top edge of the timber fascia and back on to the rafter.

#### Product Descriptions

All descriptions, specifications, illustrations, drawings, data, dimensions and weights contained in this catalogue, all technical literature and websites containing information from Lysaght are approximations only. They are intended by Lysaght to be a general description for information and identification purposes and do not create a sale by description. Lysaght reserves the right at any time to: (a) supply Goods with such minor modifications from its drawings and specifications as it sees fit; and (b) alter specifications shown in its promotional literature to reflect changes made after the date of such publication.

#### Disclaimer, Warranties and Limitation of Liability

This publication is intended to be an aid for all trades and professionals involved with specifying and installing Lysaght products and not to be a substitute for professional judgement. Terms and conditions of sale available at local Lysaght sales offices. Except to the extent to which liability may not lawfully be excluded or limited, BlueScope Steel Limited will not be under or incur any liability to you for any direct or indirect loss or damage (including, without limitation, consequential loss or damage such as loss of profit or anticipated profit, loss of use, damage to goodwill and loss due to delay) however caused (including, without limitation, breach of contract, negligence and/or breach of statute), which you may suffer or incur in connection with this publication. © Copyright BlueScope Steel Limited 3 November 2016

# WWW.LYSAGHT.COM

#### **Technical enquiries:**

#### steeldirect@bluescopesteel.com or call 1800 641 417

LYSAGHT®, SHORELINE® and NOVALINE® are registered trademarks of BlueScope Steel Limited, ABN 16 000 011 058. The LYSAGHT® range of products is exclusively made by or for BlueScope Steel Limited trading as Lysaght.

# SHORELINE<sup>®</sup> Gutter



#### SHORELINE® Mini Gutter



# LYSAGHT SHORELINE® MINI GUTTER

## **INSTALLATION TO NOVALINE® FASCIA**

- 1. Using a NOVALINE® Fascia spring clip, secure the back of the SHORELINE® or SHORELINE® MINI Gutter to the fascia.
- 2. Use a SHORELINE® MINI Gutter overstrap to secure the front scroll of the gutter, then fold the overstrap over the top of and back under the lip of the NOVALINE® Fascia.

Notes for installation of overstrap:

- a. When the gutter level is set high the overstrap should be fixed with a screw to the top of the fascia
- b. The scroll end of the overstrap should also be secured using a pop-rivet

## **INSTALLATION TO TIMBER FASCIA**

- 1. Fasten a timber fascia suspension clip to the timber fascia using #8-10x32 CSK Ribbed Head, Coarse Thread Timber screw with Climacoat 3 for treated timber. Subsequent clips can be fixed at any level on the fascia to accommodate the fall/slope of the gutter.
- 2. Secure the SHORELINE® MINI Gutter to the desired barb on the timber fascia suspension clip.
- 3. Use a SHORELINE<sup>®</sup> MINI Gutter overstrap to secure the front scroll of the gutter, then fasten to the top edge of the timber fascia and back on to the rafter.

## **OTHER CONSIDERATIONS**

- For guidance in designing a perimeter drainage system for a domestic roof, please refer to the LYSAGHT<sup>®</sup> Rainwater Solutions SA brochure available at www.lysaght.com
- 2. Testing and modelling of overflow solutions for both LYSAGHT SHORELINE® and SHORELINE® MINI undertaken by Lysaght has demonstrated that sufficient overflow capacity can be achieved in most domestic residences in South Australia to satisfy the requirements of the NCC (and reference standard AS/NZS 3500.3) to avoid any overflow back into the roof or building structure – contact your local Lysaght branch for information on these solutions relevant for LYSAGHT SHORELINE® and SHORELINE® MINI Gutters.





LYT0073 03.11.16