

## Preparation

The substrate must be flat and rigid where the panels are laid. Battens are required between the structure and the ply to create a ventilation gap to prevent condensation. Procter wrap, a breathable barrier membrane, is required between the substrate and the Nail Strip panel.

## **Material Availability**

- Colorbond®
- Colorbond® Ultra
- Colorbond® Metallic
- Colorbond® Matt
- Galvanised

## **Standard NailStrip Specifications**

			Rib Height 25mm		Rib Height 38mm	
Rib Height and Cover	r	25 x 185	25 x 285	38 x 255	38 x 345	
NailStrip Length -	1.0 - 4.0 Recommended Max					
Minimum Pitch -	7.5° Roof					
Custom Widths -	Available on request					
Notching -	20mm Rib cut back as requested					
Stop Ends -	Fold up, Fold down, Fold Hook					
Screws -	Wafer 10-12 x 25 Timber					
Colerbond	Fixing every 300mm	e		Stee	eline	
Ph. 1300 STEELIN	E steeline	.com.au		Service c	over and above	